



Agriculture and
Agri-Food Canada

Agriculture et
Agroalimentaire Canada

Replacement Class Screening Report
For
Water Well Construction and Decommissioning

July 25, 2005

Agriculture and Agri-Food Canada-
Prairie Farm Rehabilitation Administration

Canada

Acknowledgements

The development of national Class Screening Reports requires a concerted effort by a large team of people. It is my pleasure to recognize the contributions made, not only by my AAFC colleagues, but also by our partners in other federal agencies, provincial agencies, and non-government agricultural organizations. In addition to the following Replacement Class Screening Report for Water Well Construction and Decommissioning Projects, AAFC has undertaken to prepare three other Class Screening Reports:

- Soil Conservation/Erosion Control Model Class Screening Report;
- Farm Water Supply Infrastructure Model Class Screening Report;
- Small Scale Farm Infrastructure Replacement Class Screening Report.

First among those to be acknowledged for his role as lead author is Darren Thomas, Environmental Analyst, AAFC-PFRA, Prairies East. As lead author, Darren has shouldered the primary responsibility for report research and writing. In carrying out his role, Darren has demonstrated dedication and perseverance. Darren, along with the lead authors for the other three AAFC Class Screening Reports, have worked as a cohesive team to ensure that AAFC exercises a consistent and high quality national approach to the assessment of water well construction and decommissioning projects and other environmentally sustainable agricultural projects supported by AAFC. Daryl Jaques, Environmental Specialist, AAFC-PFRA, Prairies Central, assisted Darren Thomas in an advisory capacity.

From the conceptual stage through to declaration and implementation, Robyn-Lynne Virtue, Class Screening Advisor, Canadian Environmental Assessment Agency has been our constant advisor, supporter, and companion. She has indeed set the standard for client service. As a result of her years of experience with the Agency and knowledge acquired through working with other Responsible Authorities in the development of their Class Screenings, Robyn very capably guided us through the process and contributed greatly to the organization of the Class Screening Reports. AAFC is grateful to the Agency for the substantial financial support which was provided to assist in covering incremental costs of producing the class screening reports.

Regional factors and differences which are inherent within Canadian agriculture have been considered by AAFC in the development of this and other national class screening reports. To ensure that the report reflects technical aspects of farm water supply infrastructure projects across our country, a Technical Review Team was established to review and comment on the draft report. AAFC acknowledges and thanks Team members, as listed below, for broadening our geographic perspectives from the prairies to include other regions of Canada. The review process was facilitated by Ryerson Christie, XIE & Associates Ltd.

- Brett Henschel, AAFC-PFRA, Dawson Creek, BC
- Glen Brandt, AAFC-PFRA, Red Deer, AB
- John Fahlman, Sask Watershed Authority, Moose Jaw, SK

- Stan McFarlane, AAFC-PFRA, Beausejour, MB
- Scott Duff, ON Ministry of Agriculture and Food, Guelph, ON
- Richard Laroche, MAPAQ, Quebec, QC
- Mario Lapointe, MAPAQ, Quebec, QC
- Isabelle Breune/Stéphanie Larouche-Boutin, AAFC, Montreal/Quebec, QC
- Tom Byers, NB Agriculture, Fisheries, and Aquaculture, Sussex, NB
- Andrew Cameron, NS Department of Agriculture and Fisheries, Halifax, NS
- Scott Anderson, PEI Department of Agriculture, Fisheries, and Aquaculture, Charlottetown, PEI

In addition to the lead authors and members of the Technical Review Team, numerous other AAFC staff have contributed to the development of the Class Screenings. I am particularly grateful to Jennifer Edwards for her leadership in developing the proposals and laying the foundation for work to follow and for coordinating translation.

A final acknowledgement goes to all members of the national AAFC –PFRA Environmental Planning Unit for helping to ensure that the report is relevant and applicable to the provinces/region for which they are responsible.

Esther Kienholz
Manager, Class Screening Development
AAFC-PFRA
Regina, SK

Table of Contents

ACKNOWLEDGEMENTS	I
1.0 INTRODUCTION	1
1.1 DEVELOPMENT OF THE CLASS SCREENING.....	1
1.2 CLASS SCREENING AND THE CANADIAN ENVIRONMENTAL ASSESSMENT ACT	3
1.3 RATIONALE FOR REPLACEMENT CLASS SCREENING REPORT	3
1.4 CONSULTATION.....	5
1.5 CANADIAN ENVIRONMENTAL ASSESSMENT REGISTRY	5
2.0 PROJECTS SUBJECT TO CLASS SCREENING	7
2.1 PROJECTS SUBJECT TO THE CEAA	7
2.2 PROJECTS SUBJECT TO REPLACEMENT CLASS SCREENING REPORT	7
2.3 PROJECTS NOT SUBJECT TO THE REPLACEMENT CLASS SCREENING REPORT	8
3.0 PROJECT DESCRIPTIONS	10
3.1 SEASONAL SCHEDULING AND DURATION OF PROJECT	13
3.2 EFFECTS OF THE ENVIRONMENT ON THE PROJECT	13
3.3 DESCRIPTION OF PROJECT ACTIVITIES	13
3.3.1 <i>Construction</i>	14
3.3.2 <i>Operation and Maintenance</i>	17
3.3.3 <i>Decommissioning</i>	18
3.4 ACCIDENTS AND MALFUNCTION	20
4.0 ENVIRONMENTAL REVIEW	22
4.1 ENVIRONMENTAL ASSESSMENT BOUNDARIES	22
4.2 ENVIRONMENTAL SETTING	23
4.3 ISSUES SCOPING AND VALUED ECOSYSTEM COMPONENTS	23
4.3.1 <i>Description of Valued Ecosystem Components</i>	26
4.4 POTENTIAL ENVIRONMENTAL EFFECTS.....	28
4.5 MITIGATION	28
4.6 ANALYSIS AND PREDICTION OF SIGNIFICANCE OF RESIDUAL ENVIRONMENTAL EFFECTS	29
4.7 ACCIDENTS AND MALFUNCTIONS	33
4.8 CUMULATIVE EFFECTS.....	34
5.0 ROLES AND RESPONSIBILITIES	36
5.1 RESPONSIBLE AUTHORITIES	36
5.2 FEDERAL AUTHORITIES.....	36
5.3 PROVINCIAL/TERRITORIAL COORDINATION	36
5.4 THE PROPONENT	37
6.0 PROCEDURES FOR AMENDING THE REPLACEMENT CLASS SCREENING REPORT	38
6.1 TERM OF APPLICATION	38
7.0 LIST OF REFERENCES	39
GLOSSARY OF TECHNICAL TERMS	40
LIST OF ACRONYMS	44
APPENDIX 1 CONTRACT MITIGATION	45

List of Tables

TABLE 2.1: DESCRIPTION OF PROJECTS SUBJECT TO THE REPLACEMENT CLASS SCREENING REPORT . 8
TABLE 3.1: POTENTIAL PHYSICAL ACTIVITIES FOR THE ASSOCIATED PHYSICAL WORKS OF LARGE AND SMALL DIAMETER WELLS..... 11
TABLE 4.1: POTENTIAL INTERACTIONS BETWEEN PROJECT ACTIVITIES AND VALUED ECOSYSTEM COMPONENTS (VECs) 25
TABLE 4.2: RATING SYSTEM USED TO DETERMINE SIGNIFICANCE OF RESIDUAL ENVIRONMENTAL EFFECTS FOLLOWING THE APPLICATION OF MITIGATION MEASURES 29
TABLE 4.3: POTENTIAL ENVIRONMENTAL EFFECTS FOR CONSTRUCTION AND DECOMMISSIONING OF WATER WELLS..... 31
TABLE 4.4: POTENTIAL ACCIDENTS AND MALFUNCTIONS 33

List of Figures

FIGURE 1: VARIOUS TYPES OF WELLS 10
FIGURE 2: EXAMPLE OF LARGE DIAMETER WELL 12
FIGURE 3: EXAMPLE OF SMALL DIAMETER WELL 12
FIGURE 4: EXAMPLE OF DECOMMISSIONED LARGE DIAMETER WELL..... 19
FIGURE 5: EXAMPLE OF DECOMMISSIONED SMALL DIAMETER WELL 19

1.0 INTRODUCTION

Agriculture and Agri-Food Canada (AAFC), has long been involved in water well construction and decommissioning projects, either by providing funding, acting as the proponent, or by providing an interest in land. Water well construction and decommissioning projects could involve the construction, operation, modification, decommissioning or abandonment of physical works including construction and decommissioning of new water wells and the decommissioning of existing water wells. The majority of water well construction and decommissioning projects are routine, repetitive projects with predictable and mitigable environmental effects. For these projects, AAFC is a responsible authority (RA) under the *Canadian Environmental Assessment Act* (the Act), and is required to undertake an environmental assessment as early as practicable in the planning stages of the project and before irrevocable decisions are made.

Under the Agricultural Policy Framework (APF), AAFC has recently developed several multi-year national funding programs designed to enhance the overall environmental performance of agricultural operations, to secure a safe, reliable agricultural water supply, and improve economic viability of the sector in Canada. The need for this Replacement Class Screening Report (RCSR) results primarily from a very large increase in the number of water well construction and decommissioning projects funded under the current APF national programs. This RCSR will, however, also apply to similar future AAFC funding programs and to projects in which AAFC is involved either as a proponent or in cases where AAFC grants an interest in land.

In addition to supporting projects under this Class, AAFC works with provincial, other federal, municipal, industry, and other partners to increase knowledge and understanding of the ground water resource and its sustainable use in agricultural and rural areas.

Use of this RCSR will enable AAFC to streamline the environmental assessment process while maintaining a uniform high quality approach and ensuring compliance with relevant federal and provincial acts and regulations. It will also allow environmental practitioners to direct resources towards projects likely to have more substantive environmental effects. Agriculture and Agri-Food Canada will be responsible for all reporting and federal coordination requirements under the Act and this RCSR.

1.1 Development of the Class Screening

Prior to beginning the Class Screening development process, AAFC estimated the number and type of environmental assessments that might be required under the APF funding programs. Based on this information, the types of projects best suited for assessment using a class screening were determined. Water well construction and decommissioning projects were found to be an ideal candidate for use of a class screening in that they are routine, repetitive projects with predictable and mitigable environmental effects, and will result in a positive net environmental effect.

The following provides a brief overview of the major steps that were followed to develop this RCSR.

Step 1: Definition of the Project Class

Once water well construction and decommissioning projects were chosen to be assessed using a replacement class screening, the types of projects best suited for this category were established. Those projects, and the activities associated with their implementation, were identified and categorized into two main subclasses. Within these subclasses, projects were described and the type and scope of projects defined.

This description ensures that only those projects suitable for assessment using a replacement class screening are carried through the process.

Step 2: Description of the environmental effects

The second step in the process was to identify and describe the potential environmental effects that may result from projects covered by this RCSR. The typical environmental setting for each type of project was described and the typical activities associated with project implementation were determined. All of the potential effects that may arise from the interaction of these components were identified, evaluated and summarized.

Step 3: Identification of Best Practices and Mitigation Measures

Once potential environmental effects were established for each project activity, mitigation measures to reduce or eliminate those effects were identified in the third step. These measures were developed by AAFC and further refined through consultation with technical review team members. This process included the following:

- Identification of potential environmental effects that may result from the project and its associated activities;
- Identification of appropriate best practices to mitigate the environmental effects that were considered likely to occur;
- Assessment of the potential environmental effects from accidents and malfunctions;
- Assessment of the potential effects of the environment on the project;
- Consideration of the potential for cumulative environmental effects; and,
- Identification of potential residual adverse environmental effects and their likely significance.

Step 4 - Preparation of the Replacement Class Screening Report (RCSR)

In this step, the results of all of the previous steps were brought together to form the complete RCSR. The RCSR documents all aspects of the development and application of the class screening process including: project and environment descriptions; the identification of environmental effects and mitigation; and procedures for amending the class screening report.

Step 5 - Submission to the Canadian Environmental Assessment Agency (the Agency) for review and Declaration

The RCSR was submitted to the Agency for declaration in accordance with the requirements of the *Act*. As part of its 30 day public consultation process, the Agency

directly notified potentially interested organizations and individuals of the public consultation period. It also posted notices on the Agency's website and the Canadian Environmental Assessment Registry (CEAR). The Agency ensured that all of the relevant comments received were adequately addressed by AAFC within the RCSR. The RCSR was declared once the Agency determined that the issues raised in the public comments were adequately addressed, and that the RCSR met the requirements of the *Act*. An official notice of declaration was then published in the *Canada Gazette*.

1.2 Class Screening and the Canadian Environmental Assessment Act

The Act and its regulations set out the legislative basis for federal environmental assessments. The legislation ensures that the environmental effects of projects involving the federal government are carefully considered early in project planning. The Act applies to projects which require a federal authority (FA) to make a decision or take an action, whether as a proponent, land administrator, source of funding or regulator (issuance of a permit or license). The FA then becomes a RA and is required to ensure that an environmental assessment of the project is carried out prior to making its decision or taking action which would allow the project to proceed.

Most projects are assessed at a screening level. A screening systematically documents the anticipated environmental effects of a proposed project, and determines the need to modify the project plan or recommend further mitigation to eliminate or minimize the significance of these effects. Screenings are conducted for projects which are not on the *Exclusion List Regulations* or the *Comprehensive Study List Regulations* and have not been identified as requiring mediation or an assessment by a review panel.

The screening of some routine projects may be streamlined through the use of a class screening report. This kind of report presents the accumulated knowledge of the environmental effects of a given type of project and identifies measures that are known to reduce or eliminate the likely adverse environmental effects. The Agency may declare such a report appropriate for use as a class screening after taking into account comments received during a 30 day period of public consultation.

A RCSR consists of a single report that defines the class of projects and describes the associated environmental effects, design standards and mitigation measures for projects assessed within the report. It includes a conclusion of significance of environmental effects for all projects assessed by the replacement class screening. Once the Agency declares a RCSR, no further environmental assessment and decision regarding the significance of the environmental effects are required for projects within the class, provided that design standards and mitigation measures described in the report are implemented. RAs must ensure RCSRs are only used once it is ensured that design standards and mitigation measures described in the RCSR are implemented for each project.

1.3 Rationale for Replacement Class Screening Report

The applicability of the RCSR to these projects is based upon the following six criteria:

1. *Well Defined Class of Projects* – proposed construction, operation, maintenance, and decommissioning involves a number of common physical works and activities. They

are well defined in terms of the design function and purpose, equipment used, how the activities are undertaken and regulated, how and where the works are undertaken, and the likely constraint on their implementation, such as seasonal timing restrictions. They have predictable and mitigable environmental impacts, and are all triggered under the Act by AAFC.

2. *Well Understood Environmental Setting* – all physical works and activities are undertaken on land that has been previously disturbed, and currently supports agricultural operations (yard or farm sites) and/or agricultural activities (livestock, cropping, greenhouses, woodlots, and forage). Farm machinery is routinely used in or around this land throughout the year. The typical environmental settings and interactions among valued ecosystem components are well understood and not likely to vary between projects.
3. *Unlikely to Cause Significant Adverse Effects, Taking into Account Mitigation* – The projects assessed in this RCSR are similar to numerous other projects that have been assessed in accordance with the Act by AAFC as individual screenings. Based on previous experience, adverse environmental effects likely to result are known, predictable and unlikely to be significantly adverse. The implementation of best construction and management practices that include standard designs, proven mitigation measures, and compliance with provincial guidelines and regulations also help to ensure the unlikelihood of these projects to cause significant adverse environmental effects.
4. *No Project Specific Follow-Up Measures Required: Water well construction and decommissioning projects fall within the category of standard agricultural practices.* They are tried and tested solutions to water supply needs; they do not involve new or unproven technology. No project specific follow-up programs are required as there are no expected variations in predictions or effects to be monitored.
5. *Effective and Efficient Planning and Decision Making Process:* The physical works and activities associated with water well construction and decommissioning projects to be assessed using this RCSR are straightforward and routine in nature. AAFC is usually the only RA involved in these assessments. Project engineers and technicians are specialized and highly experienced in the design and construction of such projects, therefore the planning and decision making processes are straightforward. From AAFC's experience in preparing individual project screenings, it is anticipated that greater efficiency, consistency, and certainty of the environmental assessment process can be achieved through the use of the RCSR.
6. *Public Concern is Unlikely:* For numerous years, AAFC together with provincial departments responsible for groundwater have assessed and supported projects similar to those assessed in this class of projects. To date, there have been no, or very few, public concerns regarding these projects. It is, therefore, reasonable to expect that projects covered by this RCSR are unlikely to result in public concerns.

As the project class meets the necessary six criteria, the RCSR is applicable. The RCSR streamlines the environmental assessment process based on the commonalities shared by the projects subject to the RCSR and satisfies the requirements of the Act.

1.4 Consultation

During the development of this RCSR, consultation was undertaken with representatives from AAFC's seven regional offices, key APF funding programs, the various departmental teams, and the department's Agri-Environmental Policy Bureau to ensure the RCSR would meet the needs of the department, programs and requirements of the Act.

Through the establishment of a Technical Review Team comprised of representatives from AAFC, provincial partners, and the agricultural sector, environmental issues associated with the construction, operation, modification, or decommissioning of farm water well projects were identified. The Technical Review Team also provided input which ensured that all the required mitigation measures, best management practices, and design standards were captured in the RCSR. Members of the Technical Review Team are identified in the Acknowledgements.

Following its submission, the Agency conducted a 30 day public consultation on the RCSR. All comments received were taken into consideration and incorporated into the RCSR as appropriate before its declaration.

1.5 Canadian Environmental Assessment Registry

The purpose of the Canadian Environmental Assessment Registry (the Registry) is to facilitate public access to records relating to environmental assessments and to provide notice in a timely manner of assessments. The Registry consists of two components – an Internet site and a project file.

The Internet site is administered by the Agency. The RA and the Agency are required to post specific records to the Internet site in relation to a replacement screening report.

Upon declaration of the RCSR, the Agency requires RAs to post on the Internet site of the Registry, at least every three months, a statement of projects for which a replacement class screening report was used. The statement should be in the form of a list of projects, and will include:

- the title of each project for which the replacement class screening report was used;
- the location of each project;
- the date when it was determined that the project falls within the category of projects covered by the report; and
- a contact name or number.

The RA must also provide annual confirmation of cumulative effects assessment conditions to ensure no new projects cause any significant adverse environmental effects.

The project file component is a file maintained by the RA during an environmental assessment. The project file must include all records produced, collected or submitted with respect to the environmental assessment of projects and all records included on the Internet site. The RA must maintain the file, ensure convenient public access, and respond to information requests in a timely manner.

Further information regarding the Registry can be found in “The Canadian Environmental Assessment Registry”, prepared by the Agency.

2.0 Projects Subject to Class Screening

The candidate class for this RCSR is water well projects that could involve the construction, operation, modification or decommissioning of large or small diameter wells, piezometers and monitoring wells, including their associated fencing, well head protection, pump enclosures, well casing, intake screen, pumps and piping.

For application of the RCSR, projects must be undertaken on land that has been previously disturbed, and currently supports agricultural operations (yard or farm sites) and/or agricultural activities (livestock, cropping, greenhouses, woodlots, and forage). Farm machinery is routinely used in or around this land throughout the year. The construction of new works will not be carried out within a water body or contribute to the direct deposit of materials, sediments, or water into them. All provincial and local set back distances prescribed in regulations and guidelines must be observed, where they exist.

Construction of water wells can occur year round, however, in many parts of Canada construction typically occurs between the spring and fall when the ground is not frozen. Construction, installation and decommissioning of the water wells will be undertaken in accordance with provincial groundwater regulations and guidelines, where they exist. Operation of the well will comply with water allocations outlined in provincial licences, permits, and guidelines. The end result is a safe secure water supply with little possibility of pollutants contaminating the water source or any general adverse affects on the aquifer, water bodies or vegetation. A combination of mobile water well drilling and earth moving machinery (drilling rigs, water trucks, service trucks, backhoes) and hand machinery/tools, may be involved in the construction and or installation of the project.

Water well construction and decommissioning projects are carried out by the project proponent or a contractor working on their behalf. The proponent is responsible for the routine inspection and maintenance of the project.

2.1 Projects Subject to the CEAA

Water well construction and decommissioning projects are a project under the Act because they are undertakings in relation to a physical work. AAFC would “trigger” or initiate the need for an environmental assessment before it could exercise any duties, powers, or functions in relation to a project, as defined by the Act, under Section 5(1)a the proponent of a project, 5(1)b the provision of financial assistance to a project, or 5(1)c the administration of federal lands.

Projects are exempted from an environmental assessment under the Act, if they meet all the criteria set out in a section of the *Exclusion List Regulations*.

2.2 Projects Subject to Replacement Class Screening Report

The projects subject to the RCSR include those projects that are defined as projects under the Act because they are undertakings in relation to a physical work and do not fall under the *Exclusion List Regulations*. Two sub-classes of water well construction

and decommissioning projects are identified and described in Table 2.1. The full scope of the project has been assessed within each sub-class.

Table 2.1: Description of Projects Subject to the Replacement Class Screening Report

Name of Sub-Class	Description of Sub-Class Project Components
Large Diameter Well (includes bored wells/dug holes and drilled wells)	Construction, installation, expansion, operation, modification or decommissioning of large diameter or bored wells, including their associated fencing, well head protection, pump enclosures, well casing, intake screen, pumps and piping. The depth of the well is dependent on the desired completion aquifer. The project typically takes from one to several days, leaves little to no significant disturbance and vegetation is usually re-established within one growing season.
Small Diameter Well (includes drilled wells, driven wells, piezometers and monitoring wells)	Construction, installation, expansion, operation, modification or decommissioning of small diameter or drilled wells, along with monitoring wells and piezometers, including their associated fencing, well head protection, pump enclosures, well casing, intake screen, pumps and piping. The depth of the well is dependent on the desired completion aquifer. The project typically takes from one to several days and leaves little to no significant disturbance and vegetation is usually re-established within one growing season.

2.3 Projects Not Subject to the Replacement Class Screening Report

The projects not subject to the RCSR include those projects that:

- Are not covered by the projects described in *Section 2.0: Projects Subject to this Class Screening* or *Section 3.0: Sub-Class Descriptions*;
- Are listed in Table 2.1 but will not implement the relevant mitigation stated in this RCSR, as required by AAFC;
- Require a permit, approval or authorization from another federal department (i.e. RA other than AAFC);
- Require assessment because they are captured in the *Comprehensive Study List Regulations*;
- Require an assessment under provincial environmental assessment legislation;
- Are constructed within a water body;
- Are carried out within a National Park, Migratory Bird Sanctuary, National Wildlife Area, provincially designated site of special concern, or on First Nation lands;
- Infrastructure intended for a group or community;
- Are likely to have an adverse effect on species at risk, either directly or indirectly, such as by adversely affecting their habitat, and/or that would require a permit under the *Species at Risk Act (SARA)*. For the purposes of this document species at risk include:
 - species that have been recognized as “at risk” by the Committee on the Status of Endangered Wildlife in Canada (COSEWIC) or by provincial or territorial authorities;
 - species identified on the List of Wildlife Species at Risk set out in Schedule 1 of SARA, and including the critical habitat or the

residences of individuals of that species, as those terms are defined in subsection 2(1) of SARA;

Water well construction and decommissioning projects that meet any of the above criteria are not addressed by this RCSR, and therefore require individual environmental assessments.

3.0 Project Descriptions

Class Description

Water wells are stable or cased holes into an underlying aquifer which produces a volume of water suitable for a variety of uses. Water wells can be located wherever an adequate supply of groundwater exists; there is no common location for the installation of water wells. Groundwater is the preferred water supply source in most rural areas of Canada because of its widespread availability and marked degree of drought tolerance.




Figure 1: Various Types of Wells

The situation surrounding wells often changes. For various reasons, many wells are abandoned and left unused, or dormant, for years. Often, these wells are still viable sources of water. Abandoned, or poorly managed, wells can act as a conduit for entry of surface pollution into the well and contaminate the entire aquifer. Proper decommissioning procedures can prevent contamination from occurring.

Decommissioning of wells generally includes the removal of pumping equipment, disinfection of the borehole or well casing, infilling of the bore hole or well casing with cement grout or bentonitic clay material to prevent the vertical movement of water, removal of the upper casing section if practical, and covering, mounding and re-vegetating the well site.

This RCSR applies to water well projects which do not meet the exclusion requirements of S. 5 or S. 19 of the *Exclusion List Regulations*. Projects in this RCSR include:

- The construction and decommissioning of scientific data collection instruments (permanent piezometers – S.5)
- the construction and decommissioning of newly constructed water wells (S.5); and
- the decommissioning of previously existing wells.

The procedures and activities associated with the construction, operation, maintenance, and decommissioning of water wells are routine activities which are usually covered

under provincial or territorial jurisdiction and have predictable environmental impacts that can be addressed with standard mitigation.

Two sub-classes and components, distinguished by their diameter, are described in this section: Large Diameter Wells and Small Diameter Wells.

Table 3.1: Potential Physical Activities for the Associated Physical Works of Large and Small Diameter Wells

Project Phase	Physical Works and Activities	Sub-class A – Large Diameter Well	Sub-class B – Small Diameter Well
Construction	Site planning and Selection	•	•
	Site Access	•	•
	Vegetation Clearing and Grubbing	•	•
	Operation of Hand Machinery	•	•
	Operation of Heavy Equipment, Vehicles	•	•
	Construction of Well Components	•	•
	Disinfection	•	•
	Earthworks	•	•
	Seeding/Planting	•	•
Operation and Maintenance	Operation of Hand Machinery	•	•
	Operation of Heavy Machinery	•	•
	Operation of Well components	•	•
	Disinfection	•	•
Decommissioning	Operation of Heavy Equipment, Vehicles	•	•
	Removal of Well Components	•	•
	Disinfection	•	•
	Earthworks	•	•
	Seeding/Planting	•	•

Sub-class A – Large Diameter Well




Figure 2: Example of Large Diameter Well

This sub-class applies to the construction, installation, expansion, operation, modification or decommissioning of large diameter wells and their associated fencing, well head protection, pump enclosures, well casing, intake screen, pumps and piping. Large diameter wells are large in diameter and relatively shallow. The depth of the well is dependent on the desired completion aquifer and is limited by the methods of construction, equipment used, and practical considerations for structural integrity and depth. The types of wells that can be included in this subclass are dug, excavated or bored wells.

These projects typically require from one to several days to complete, and leave little to no significant disturbance on the area around the well site. The vegetation and soil integrity is usually re-established within one growing season.

Sub-class B – Small Diameter Well

This sub-class applies to the construction, installation, expansion, operation, modification or decommissioning of small diameter wells, piezometers and monitoring wells, and their associated fencing, well head protection, pump enclosures, well casing, intake screen, pumps and piping. Small diameter wells are those wells that are significantly smaller in diameter and usually deeper than the large diameter wells. The depth of the well is dependent on the desired completion aquifer and is a more feasible option in areas of deep aquifers. Types of wells that can be included in this sub-class are drilled (including mud rotary, air rotary and air hammer drills), small bored, cable-tool (percussion), driven-point or jetted wells.




Figure 3: Example of Small Diameter Well

These projects typically require from one to several days to complete and leave little to no significant disturbance on the area around the well site. The vegetation and soil integrity is usually re-established within one growing season.

3.1 Seasonal Scheduling and Duration of Project

Wells can be installed at any time of the year, but due to machinery operations and effectiveness, and worker considerations, water wells are usually installed when extreme weather conditions are least likely to occur and soil moisture conditions permit access and movement of heavy equipment.

Site preparation and construction activities typically may last from less than one day to a few days, depending on the scale of the project. Modification, maintenance, or repair activities are generally shorter in duration unless a major change is required. In the latter case, the project may take as long as the original construction to complete. Decommissioning and abandonment activities may take as long as the original construction to complete.

3.2 Effects of the Environment on the Project

Under the Act, an environmental assessment must consider potential effects which the environment may have on the project. Activities relevant to water well construction and decommissioning are vulnerable to a variety of environmental effects such as:

- extreme weather events (such as temperatures and precipitation) that may cause problems for machinery operation and drill crews during construction or decommissioning;
- formation drilling that may require more drilling fluid materials;
- rainfall and flood events that may introduce foreign material into a well and adversely affect water quality; or
- rainfall and flood events that may erode site structures.

The effects identified are considered mitigable and avoidable through design and siting, the use of best construction practices, as accepted by industry and the use of standards for operating, maintenance and repair procedures. These specific mitigations are covered in Section 4.0 of this RCSR.

3.3 Description of Project Activities

The proposed construction, installation, operation, maintenance and decommissioning of water well projects involve a number of common physical works and activities, as described below. They represent the manner in which water wells are typically implemented throughout each phase of development. Mitigation measures, as described in *Section 4: Environmental Review*, may be required to ensure no significant adverse environmental effects occur.

The primary difference between activities associated with Large Diameter and Small Diameter wells lies in the methods used to construct the well components. Unless otherwise stated, the following project activities are undertaken for both types of well projects.

3.3.1 Construction

Site Planning and Site Selection

Project planning involves identifying relevant local, provincial, and federal regulations that must be complied with as well as guidelines and best construction practices for siting and construction of projects; attaining necessary approvals and authorizations of relevant local, provincial/territorial, and federal regulations; consulting with technical experts where appropriate; obtaining engineering advice where appropriate; selecting the project site; project design; determining the work schedule; and completing the environmental assessment, when required.

The site selected for a water well should be located away from potentially polluting influences, with ground sloping away from the well site, and in an area not prone to flooding events. The well will be located in an area with high potential for adequate water supply. Site selection will take into consideration previous and existing well sites and depths in the surrounding area. Provincial/territorial and local legislation, regulations, guidelines or polices should be consulted to determine obligations required for site selection.

Site Access

In some areas a temporary access may be required to allow site access by drilling equipment, a water truck, and auxiliary equipment trailers. Modifications are rarely made to the landscape for temporary access and vegetation clearing is minimal. A temporary access is used only for the purpose of the water well construction and will not be a permanent landscape feature. Where possible, project site access will be confined to, or near, existing roads and rights-of-way. Site access will utilize natural clearings, be located on land that has been previously disturbed, and/or currently supports agricultural operations (yard or farm sites) or agricultural activities (livestock, cropping, greenhouses, woodlots, and forage).

Vegetation Clearing and Grubbing

Depending on the condition of the project site, some vegetation removal may be required to provide sufficient open space to construct the project and/or provide access to the project site. This may involve cutting, clearing, and grubbing of the area using heavy or hand equipment, depending on the vegetation type and size, and site accessibility.

Operation of Hand Machinery/Tools

Hand machinery/tools may be used during a project. Hand machinery/tools may include items such as weed whips, chain saws, shovels, cement mixers, power tools, seeding and spraying equipment. Fuel is used by certain hand machinery. Re-fuelling and storage of fuel may be required at or near the project site.

Operation of Heavy Equipment and Vehicles

A variety of heavy equipment/machinery may be used during a project. The drilling process involves the use of heavy machinery (drilling rig or back hoe, water truck) and other vehicles and equipment that may be related to the drilling and completion process (equipment trailer, light and heavy duty trucks). A variety of vehicles, such as light-duty trucks, trailers, and ATV's, may be used to access the project site. Re-fuelling and storage of fuel may be required at, or near, the project site.

Construction of Well Components

The major components involved in a typical well installation tend to be similar from one project to another, although there may be some variation in diameter and length of some components.

The following project descriptions will separate work activities associated with the individual components of each project, rather than describing each type of system.

Sub-class A – Large Diameter Well

Drilling

Large diameter wells can be excavated or dug by hand or by heavy machinery, such as a backhoe. The hand dug method is not widely used today, however, in the past these types of wells were common place. The holes were dug in the hope of encountering a shallow aquifer. The holes were then stabilized using a variety of materials such as wood, stones, bricks, tile or concrete. The well was then covered using wood, stone or concrete covers. Equipment such as backhoes can be used to excavate a large diameter well, but these too are restricted to a certain depth.

Bored wells can be dug using a rotating earth auger, or more commonly a bucket-type excavator. The auger or bucket is rotated by hydraulic power, and bores the hole to the required depth. The auger bit carries the earth to the surface, while the bucket picks up the excavated materials which are then raised from the hole. The excavated materials are then deposited on the surface. Bored wells are smaller in diameter and are completed to greater depths compared with excavated or dug wells.

Casing

A casing is inserted into the shaft in order to improve the stability of the shaft. The casing is made from a variety of materials, including but not limited to, corrugated steel, PVC, fibreglass or concrete. In some older wells, bricks, stones, wood or tiles may have been used to stabilize the shaft. Materials used for casings will be determined by provincial/territorial or local legislation, regulations, guidelines, or policies or by site conditions.

Screen

A screen is placed at a location on the casing that is adjacent to the desired aquifer zone. The screen allows the water to seep into the pipe. The screening can consist of or be manufactured in a variety of ways including, but not limited to, manufactured steel around the casing or machine cut openings into the casing itself. The casing is then installed in the drilled shaft, with either a manufactured or custom well screen set at a predetermined interval in the well casing to accommodate water flow into the well. Methods used for screening and screen heights will be determined by provincial/territorial or local legislation, regulations, guidelines, or policies or by site conditions.

Well Development

Construction of well components may also involve well development, pump installation, connection to the water system, test holes, pump testing, disposal of pump test water, and disposal of contaminated water. These activities should be followed as prescribed in the provincial/territorial or local legislation, regulations, guidelines or policies and/or by site conditions.

Backfill

The annular space between the screened well casing and drilled hole is usually backfilled with pervious material to within a few metres above the screen, then backfilled to the surface with impermeable materials to form an impermeable seal. Methods and materials used for backfill and sealing may be determined by provincial/territorial or local legislation, regulations, guidelines, or policies or by site conditions.

Sub-class B – Small Diameter Well

Drilling

Types of wells that can be included in this sub-class are drilled (including mud rotary, air rotary and air hammer drills), small bored, cable-tool (percussion), driven-point or jetted wells. Piezometers and monitoring wells constructed using similar methods are also included in this sub-class.

Most modern wells are drilled using some kind of rotary method, which requires a drill rig mounted on heavy truck platforms. They utilize rotary drill bits that penetrate subsurface materials, or percussion bits that pulverize the materials encountered. If the ground is soft, or the target aquifer is shallow, small diameter auger bits may be used.

Driven wells are constructed by driving a small-diameter pipe into shallow water-bearing sand or gravel. Usually a screened well point is attached to the bottom of the casing before driving. These wells are relatively simple and economical to construct, but they have limited applicability with respect to depth and materials that can be penetrated. These types of wells can be easily contaminated from nearby surface sources because a significant annular space is not created during the driving process, and therefore sealing material such as grout can not be used to seal the well.

Jetted wells use a high velocity stream of water to excavate the hole and to carry the material out of the hole. This method requires a supply of water and a high pressure pump. This method depends on the erosive action of water; therefore it is only suitable for limited drilling mediums. Extremely hard materials cannot be penetrated; semi-hard materials may be penetrated by a combination of hydraulic and percussion effects, while coarse materials such as gravel require a greater water velocity to move the cuttings vertically out of the hole than do finer materials. Very fine, hard packed materials, such as clay, require a high water velocity to dislodge the material.

Casing

A casing is inserted into the bore hole to improve the stability of the bore hole. The casings can be made from a variety of materials, including but not limited to steel, black iron, PVC, fibreglass or plastic. Materials used for casings will be determined by federal, provincial/territorial or local legislation, regulations, guidelines, policies or by site conditions.

Screen

A screen is usually attached to the bottom of the casing in most cases (exceptions can include some bedrock wells). The screen allows the water to seep into the casing. The screen can consist of a variety of materials including steel or plastic. The casing is then installed in the bore hole, with the screen set at a predetermined interval to accommodate water flow into the well. Methods used for screening and screen heights

will be determined by provincial/territorial or local legislation, regulations, guidelines, or policies or by site conditions.

Well Development

Construction of well components may also involve well development, pump installation, connection to the water system, pump testing, disposal of pump test water, and disposal of contaminated water. These activities should be followed as prescribed in the local legislation, regulation, guidelines or policies, or by site conditions.

Backfill

The annular space between the screened well casing and drilled hole is usually backfilled with pervious material to within a few metres above the screen, then backfilled to the surface with impermeable materials to form an impermeable seal. Methods and materials used for backfill and sealing may be determined by provincial/territorial or local legislation, regulations, guidelines, or policies or by site conditions.

Disinfection

Drilling of a well, or the addition of the casing or the sealing materials, may introduce bacteria into the well and surrounding aquifer. Wells should be disinfected by shock chlorination, or other approved/acceptable means of disinfection, prior to capping. Provincial/Territorial or local legislation, regulations, guidelines or policies should be consulted, where they exist, as to proper disinfection techniques. Where such are not in place, industry accepted best practices should be followed for disinfection procedures.

Earthworks

Earthwork activities, such as stockpiling, removal and handling of soil and cuttings, and sloping may need to be undertaken as part of a project, with the site sloped to allow precipitation or surface water to flow away from the well site. Operation of a combination of heavy equipment, vehicles, and hand machinery/tools may be required.

Seeding and Planting

Re-vegetation of disturbed areas involves the use of pre-existing or other suitable vegetation, and may include final site sloping, direct or broadcast seeding, sodding, transplanting, fertilizing, establishment control, and site monitoring. In many cases, the footprint of the site is small and therefore the site is left to re-vegetate naturally.

3.3.2 Operation and Maintenance

Operation of Well Components

Once the construction of the water well is complete and the piping and pump are in place, the water is utilized for purposes which are generally located away from the well system. Much of the operation, or usage of the water, does not directly interact with the well site. An important factor to consider when operating a well is the withdrawal limits which may be set as per provincial/territorial licence, permits, guidelines, agreements or through technical data. If the limits of the well are exceeded, problems related to water quality or quantity in and around the project area may arise.

Once the well has been constructed, sealed and capped, the well needs little attention except for periodic maintenance and checking. Well head protection (steel posts, fence) may be used and the area around the well head may be modified to ensure that surface water runs away from the well head. The power supply may be either by a connection to

a nearby pole, underground lines or possibly, solar panels. Water is pumped to discharge points through buried pipelines. Hydrants may be connected to the line at various points of convenience.

Operation of Hand Machinery

Hand machinery, such as brush saws, power tools and hand tools, may be used to maintain the access.

Operation of Heavy Machinery

Heavy machinery may be used to repair the well and associated piping if malfunctions occur. Heavy machinery can include drilling rigs, water trucks and cranes.

Disinfection

The well may require periodic disinfection for a variety of reasons. Bacteria may be introduced into the subsurface from a variety of sources such as repairs or maintenance of the well or other wells or activities in the area. Shock chlorination of the well can be used to help reduce the impact of these occurrences.

3.3.3 Decommissioning

This RCSR applies to the decommissioning of new wells constructed under this RCSR as well as those constructed and abandoned prior to this RCSR.

An abandoned well is defined as a well for which use has been permanently discontinued or is in an advanced state of disrepair, and can not be used for its intended purpose. The many abandoned wells in Canada pose a threat to both human safety and groundwater quality as they act as a conduit for the movement of near-surface contaminants, such as farm wastes, pesticides, fuel and other chemicals from leaking storage tanks, septic system wastes, and storm water run-off, into the underlying aquifer. Larger diameter, open, unused wells also present a physical hazard for animals and humans.

Activities involved in decommissioning a well may vary considerably depending on the type of well casing and the well depth and diameter. Examples of such activities include removal of the well casing, removal of pumping equipment, disinfection of the well, filling of the borehole with an impervious substance, backfilling the area with clay and adding topsoil at the surface. Re-vegetation occurs naturally or through seeding.




Figure 4: Example of Decommissioned Large Diameter Well




Figure 5: Example of Decommissioned Small Diameter Well

Efforts are rarely made to properly decommission a water well. Methods and proper procedures for decommissioning a well are determined by provincial/territorial guidelines or regulations, where they exist. In some provinces, well decommissioning is highly regulated while, in others, decommissioning is broadly defined.

Site Access

In some areas a temporary access may be required to allow site access by drilling equipment, a water truck, and auxiliary equipment trailers. Modifications are rarely made to the landscape for temporary access and vegetation clearing is minimal. A temporary access is used only for the purpose of the water well decommissioning and will not be a permanent landscape feature. Where possible, project site access will be confined to, or near, existing roads and rights-of-way. The site access will utilize natural clearings and be located on land that has been previously disturbed, and/or currently supports agricultural operations (yard or farm sites) or agricultural activities (livestock, cropping, greenhouses, woodlots, and forage).

Operation of Heavy Equipment

The decommissioning process involves the use of heavy machinery (such as back hoe, cat, grader, drilling rig) and other vehicles and equipment (such as equipment trailer, ATVs, shelter). A variety of vehicles, such as light-duty trucks and trailers, may be used during a project, particularly to access the project site and possibly to complete the project. Re-fuelling and storage of fuel may be required at or near the project site.

Closure of a Well

Removal of the pump and related infrastructure, if necessary, is a logical first step in the well decommissioning process. The next step may involve removal of the upper portion of the casing, depending on the provincial/territorial or local requirements. Once the casing is removed, the area should be backfilled with an impervious material, graded to slope away from the former well, covered with topsoil and seeded. If the well casing cannot be removed, then it should be cut off below ground after it has been filled.

The selection of the material type used to seal the well is very important. The sealing procedures can often be found in provincial/territorial or local regulations or guidelines, where they exist. The type of material used to seal the well will help determine how effective the capping will be in preventing contamination.

Aside from choosing the appropriate plugging material, the method of placing material into the well is critical. Regulations and guidelines, where applicable, may require that the plugging material be introduced in a manner as to fill the well shaft from the bottom of the well and progressively upward to ground surface.

As a final step the excavation is backfilled with an impervious material, graded to slope away from the former well, covered with topsoil and seeded.

Provincial/territorial or local legislation, regulations, guidelines or policies should be consulted as to proper closure techniques as some jurisdictions may have additional requirements for decommissioning.

Disinfection

Sealing a well may cause a temporary silty or cloudy appearance to the water in nearby wells, particularly in areas where wells are constructed in fractured bedrock aquifers, such as limestone. Bacteria may also be introduced into the subsurface when adding sealing materials. Wells should be shock chlorinated. Wells may be shock chlorinated by adding one gallon of household bleach for every 50 gallons of water in the well. Provincial/territorial or local legislation, regulations, guidelines or policies, where available, should be consulted as to proper disinfection techniques.

Earthworks

After the well has been filled and sealed, it must be capped. A variety of methods can be used to cap a well, depending on the method used to seal the shaft. Local regulations and guidelines may indicate the appropriate method of capping the well. If top soil is used to cover the well, it should be mounded so that surface water will always drain away from the well. The well should also be mounded to allow for settling in the immediate area of the well.

Seeding and Planting

Well sites are usually left to re-grow naturally but may be replanted to help the site re-vegetate.

3.4 Accidents and Malfunction

The drilling and decommissioning processes involve the use of heavy machinery and other vehicles and equipment (equipment trailer, light and heavy duty trucks). As such,

there is potential for accidental leaks of hydrocarbons, lubricants, or cooling fluids from the vehicles, either during their normal operation or during re-fuelling and maintenance procedures.

Geological factors may contribute to an accident or malfunction. There is the potential for drilling fluids to leave the confinement of the construction area and enter the surrounding environment through formation fractures in the bore hole. This is of particular concern when the well is located near a water body or close to other well sites.

Problems may arise due to erosion, water logging, declining water levels, or flooding from pump testing or to natural environmental factors, such as extreme precipitation events. These problems are difficult to forecast, however, they should be recognized as possible occurrences.

In some drilling techniques, various liquids are used, such as chlorinated water for disinfection, or drilling fluids used in drilling. These liquids can escape and damage the local flora and fauna, or may contaminate local water bodies or sources.

In drilling a well, unexpected risks such as flowing wells or entrained gas may be encountered. Flowing wells pose a risk of contamination of a nearby water source, while encountering gas can pose a health risk or risk from fire and explosions.

There is always a possibility of equipment malfunction or human error. In the case of malfunctions, equipment may not perform to expectation or break down unexpectedly. Human error may cause for unplanned events to occur. In either case a variety of occurrences could happen that might have an effect on the environment. These problems are difficult to forecast, however, they should be recognized as possible occurrences.

When working in the natural environment, there is always the potential for fires to occur. Whether the fire was created by natural causes or by project related activities, it still has the potential to affect the environment. Fire can also pose a risk to health and safety.

4.0 ENVIRONMENTAL REVIEW

This section outlines the methodology used to ensure that the effects of project activities on the environment are consistently addressed from project to project regardless of location. To accomplish this, Valued Ecosystem Components (VECs) have been identified. VECs are those ecosystem components most likely to be affected by a project, and those features thought to be most important, thereby warranting further analysis. Potential environmental effects on selected VECs, which include cumulative and residual effects, are identified and the rationale for their analysis is explained. Accidents and malfunctions, including the effects of the environment on the project, are also considered. The process for selecting mitigation measures to address and alleviate these effects on each VEC is discussed. A rating system is applied to establish the significance of residual environmental effects (i.e., effects remaining after the application of mitigation measures), based on the magnitude, geographic extent, duration, frequency, and permanence of the effect.

4.1 Environmental Assessment Boundaries

An important aspect of the environmental assessment process is the determination of the study boundaries. Study boundaries serve to focus the scope of the work such that a meaningful analysis of potential effects arising from the proposed project can be made. Study boundaries may be influenced by restrictions imposed by project scheduling and the varying degree to which environmental effects can be quantified and objectively evaluated (i.e., the point at which an environmental effect can no longer be measured, noticed or observed).

A boundary is a function of the extent and duration of potential interaction between a proposed project and VECs. Generally, these boundaries are defined by the temporal and spatial characteristics encompassing those periods and areas, during and within which, the VECs are likely to interact with, or be influenced by, the project. The environmental assessment boundary for water well construction and decommissioning projects is defined by the spatial and temporal extent of the similar physical characteristics of the project location. The projects covered under this RCSR are regularly conducted, routine projects. Project boundaries may vary slightly for individual project sub-classes.

Temporal boundaries include all project phases; from site preparation through to decommissioning. Project activities for water well construction and decommissioning projects continue on a year round basis, however, most are initiated in spring, summer, or fall seasons. They can last from less than one day to several days, depending on work specifics. The temporal boundaries are dependent on the particular project phase and time of year it is undertaken. This has been considered in the assessment and addressed for each VEC; specific details are provided in *Section 4.3: Issues Scoping and Valued Ecosystem Components*.

The spatial boundary encompassing the potential effects of a project is generally expected to be limited to the immediate project area. The majority of potential effects are not expected to occur beyond this spatial extent; however some effects may extend beyond the limits of the project area for certain VECs. Spatial boundaries have been

considered in the assessment and addressed for each VEC. Specific details are provided in *Section 4.3: Issues Scoping and Valued Ecosystem Components*.

Administrative boundaries have also been considered during the development of the replacement class screening report. Both federal and provincial/territorial requirements have been considered and addressed.

In assessing and comparing the nature and limited affected areas of proposed projects, versus the defining scales of ecological and socioeconomic boundaries, it is felt that temporal, spatial and administrative boundaries alone properly identify potential environmental effects of defined projects. Accordingly, ecological and socioeconomic boundaries were not considered further, as this would not add to the quality of the replacement class screening and would only replicate previously identified effects.

As project use of new technology or technology with uncertain effects is unlikely, technical boundaries were not considered.

4.2 Environmental Setting

Since the projects subject to this RCSR are well defined, mitigation measures are well established, and potential environmental effects are well understood, detailed descriptions of environmental settings for projects subject to the RCSR have not been provided. However, general descriptions of environmental settings are provided in *Section 3.0: Project Class Descriptions*.

For application of the RCSR, projects must be undertaken solely on land that currently supports agricultural operations (i.e. yard or farm sites) and/or agricultural activities (i.e. livestock, cropping, greenhouses, woodlots, forages); and the land must have been previously disturbed in some form. The physical works cannot be carried out in a water body or contribute to the direct deposit of materials or sediments into them. Farm machinery is routinely used on or around this land, often throughout the year. Given this present land use, wildlife present in the area will be accustomed to normal agricultural activities, including the sounds and movement of farm machinery present in such a setting. It is, therefore, unlikely that wildlife will be adversely affected by proposed projects under this RCSR.

4.3 Issues Scoping and Valued Ecosystem Components

Using their experience in project assessment, planning and implementation, AAFC conducted an issues scoping process to:

- Identify all project activities associated with each water well construction and decommissioning sub-class;
- Identify VECs for water well construction and decommissioning projects; and
- Establish a matrix of potential interactions between identified project activities and VECs.

Various other expert authorities were consulted as part of this process, including: provincial/territorial agriculture, water resource, wildlife and fisheries departments, and the Agency.

The matrix describing potential interactions between project activities and VECs is shown in Table 4.1.

Table 4.1: Potential Interactions between Project Activities and Valued Ecosystem Components (VECs)

Project Phase	Physical Works and Project Activities	VECs ¹											
		Air Quality	Terrain and Topography	Soils	Surface Water Hydrology	Surface Water Quality	Groundwater Quantity	Groundwater Quality	Aquatic Habitat and Species	Terrestrial Habitat and Species	Land and Resource Use	Socio-Economic Conditions	Cultural and Heritage Resources
Construction	Site planning and Selection												
	Site Access			•		•				•			•
	Vegetation Clearing and Grubbing			•		•				•			
	Operation of Hand Machinery/Tools			•						•			
	Operation of Heavy Equipment, Vehicles			•				•		•			•
	Construction of Well Components			•		•	•	•					•
	Disinfection							•					
	Earthworks			•		•				•			•
Seeding/Planting			•						•				
Operation and Maintenance	Operation of Hand Machinery/Tools			•						•			
	Operation of Heavy Equipment, Vehicles			•		•		•		•			•
	Operation of Well Components						•	•					
	Disinfection					•		•					
Decommissioning	Operation of Heavy Equipment, Vehicles			•						•			•
	Closure of Well Components					•	•	•		•			
	Disinfection					•		•					
	Earthworks			•		•				•			•
	Seeding/Planting			•						•			

¹ A – Applies to Subclass A (Large Diameter Wells), B – Applies to Subclass B (Small Diameter Wells), • – Applies to all classes

It has been determined that no measurable adverse environmental effects will occur on the following VECs, based on the limited duration, frequency and spatial extent of the potential interactions outlined in Table 4.1, with routine water well construction and decommissioning:

- Air Quality
- Terrain and Topography
- Surface Water Hydrology
- Aquatic Habitat and Species
- Land and Resource Use
- Socio-Economic Conditions

These components will not be carried forward through the RCSR for further detailed analysis. In the unlikely events that these VECs could be indirectly affected, it is presumed that the mitigation developed for the RCSR will serve to address any potential effects on the unconsidered VECs.

4.3.1 Description of Valued Ecosystem Components

The following VECs have been identified as potentially susceptible to significant adverse environmental effects due to project activities. The value of each VEC, and possible interactions with project activities, is also described.

Soils

Soils are important as they are directly connected to agricultural productivity and economic sustainability of the industry. Healthy soils support biological diversity and promote agricultural quality. Well-managed soils have high moisture-absorbing capacities, which can reduce the intensity of runoff and thus reduce potential erosion and loss of soil resources. Project activities, could result in a number of environmental effects, including: erosion or slope instability due to increased soil exposure and reduced soil capability through soil compaction and mixing and soil contamination through unsafe handling, storage or the accidental spills of fuels, hazardous material or wastes.

The spatial boundary for this VEC is set to the project site. The effects of the project activities will be felt for the length of time required to complete all project activities and, in some cases, the length of time that the project is in operation. In certain instances, effects will be felt for the length of time it takes for the project site to be restored to preconstruction conditions, as disturbed areas will continue to be affected until appropriate restoration takes place. The generally minor effects felt by the introduction of contaminants are likely to be rare and small in magnitude. If they occur, they will affect only the immediate surface area, and will be appropriately removed and disposed of in an appropriate manner.

Surface Water Quality

Surface water quality is valued as it influences the health of humans, fish and wildlife, livestock, and the environment as a whole. It is frequently relied upon as a water source, often satisfying water requirements by agricultural operations. Surface water quality has the potential to be reduced by project activities, through an increase in sediment loads which may occur through poorly planned or implemented excavation activities, or by the accidental introduction of contaminants such as oil, grease or fuel spills from construction vehicles or equipment, directly or indirectly into surface water bodies.

The spatial boundary for this VEC is set to the project site and any receiving water bodies. Effects to surface water quality will not extend past the length of time it takes to restore the project site to pre-construction conditions. The generally minor effects felt by the introduction of sediments will be limited to the length of time and reach it takes for introduced sediments to fall out of suspension.

Groundwater Quantity

Water is critical to the success of an agricultural operation. Groundwater is a valued source of water and is frequently relied upon as a source of drinking water and often used to satisfy water requirements during agricultural operations. Groundwater aquifers are not always isolated entities; shallow aquifers can be linked with other surface water sources such as lakes, rivers and streams through discharging and recharging areas. This interaction between shallow aquifers and surface water is often integral to the survival of either system. Projects could negatively affect groundwater quantity through water withdrawal during project activities. Withdrawal could result in changes to groundwater flow patterns, groundwater levels and subsequently, well yields.

The spatial boundary for this VEC is set to the project site and the area of influence within the associated aquifer. Direct effects of project activities on groundwater quantity will rarely be felt indefinitely; however, aquifer depletion could result from extended drought conditions, or if sustainable yields are exceeded for long periods of time. In most cases, the effects of groundwater withdrawal will be felt temporarily until proper withdrawal rates and sustainable yields are determined.

Groundwater Quality

Water is critical to the success of an agricultural operation. Groundwater is a valued source of water and is frequently relied upon as a source of drinking water and often used to satisfy water requirements during agricultural operations. Groundwater aquifers are not always isolated entities, shallow aquifers can be linked with other surface water sources such as lakes, rivers and streams through discharging and recharging areas. Groundwater quality is valued as it influences the quality of linked water sources and the health of humans, fish and wildlife, livestock, and the environment as a whole. Through proper well decommissioning, groundwater quality is protected by eliminating potential pathways for contaminants to reach aquifers. Projects could, however, negatively affect groundwater quality through the accidental introduction of contaminants to the associated aquifer.

The spatial boundary for this VEC is set to the project site and the associated aquifer. Any direct effects of project activities on groundwater quality may be felt for an indefinite period. Taking into account mitigation and accepted industry practices, the quantity of contaminant that may potentially reach the aquifer following a spill or machinery malfunction would be very small, and active remediation techniques would likely not be employed.

Terrestrial Habitat and Species

Terrestrial habitat and species are valued as individuals, habitat, and key components of biological diversity. Special value is given to rare or uncommon species since loss of individuals of such species has the greatest potential to affect the ecological integrity of an area. Projects could negatively affect terrestrial habitat and species by the

disturbance/destruction of vegetation and habitat, the introduction of non-native species and opportunistic species, or the disruption to wildlife nesting and rearing activities.

The spatial boundary for this VEC is set to the project site. The effects of the project activities will be felt temporarily, until suitable natural recovery and re-vegetation has taken place, and visual evidence of all activities fade. Thus, identified effects of project activities will be felt until project site is restored to a state equivalent to preconstruction conditions.

Cultural and Heritage Resources

Cultural and heritage resources include cultural landscapes, archaeological and paleontological sites, structures, engineering works and artifacts, and any other associated records assigned important historic value. Cultural resources are valued for their association with aspects of human history and their contribution to the understanding of past events. Project activities have potential to damage surface and below ground cultural resources, and affect cultural and heritage resources through loss and/or disruption.

The spatial boundary for this VEC is set to the project site. Depending on the nature of the cultural and heritage resource, the effects of project activities will be felt temporarily until the resource can be appropriately restored or indefinitely in the unlikely event that a resource is destroyed before or during project construction.

4.4 Potential Environmental Effects

The environmental assessment focuses on the evaluation of potential environmental effects resulting from interactions between the various project components/activities and the VECs for each project phase. While many of these projects will result in an overall net-positive result, only potential adverse environmental effects are identified.

The environmental effects resulting from project-environment interactions will, for the most part, take place during the construction phase; however, effects can still occur during all phases of the project. The spatial and temporal environmental effects will be limited to the boundaries identified in *Section 4.3.1 Description of Valued Ecosystem Components*. The nature of these effects is related to: Soils, Surface Water Quality, Groundwater Quantity and Quality, Terrestrial Habitat and Species, Cultural and Heritage Resources.

Each type of project in the 2 sub-classes considered within this RCSR was analyzed on a subclass basis. Table 4.3 identifies the potential adverse environmental effects for the VECs deemed relevant in *Section 4.3: Issues Scoping and Valued Ecosystem Components* for each project sub-class.

4.5 Mitigation

Mitigation measures are those measures identified as a means of eliminating, reducing or controlling adverse environmental effects resulting from project activities, and are components of proper project planning, site preparation, construction and restoration practices. Table 4.3 identifies the mitigation measures that should be enlisted to eliminate, reduce or control potential adverse environmental effects on identified VECs, as a result of project activities. This includes the effects of related accidents and

malfunctions. If all applicable mitigation identified in Table 4.3 is employed, water well construction and decommissioning projects are not likely to cause significant adverse residual environmental effects.

Water well construction and decommissioning projects which fall within this RCSR involve routine projects with predictable environmental effects that can be avoided or minimized using proven mitigation.

In order to ensure that conditions of funding, including mitigation, provided to the proponent have been successfully completed, AAFC will provide technical advice to selected projects during project planning, and may, upon completion of the project, conduct either telephone interviews or site visits to selected projects.

Site visits will also provide AAFC staff with greater understanding of the on the ground nature and benefits of the projects. AAFC staff will conduct site visits to all completed projects for which they are the proponent or grant an interest in land.

4.6 Analysis and Prediction of Significance of Residual Environmental Effects

Analysis and prediction of the significance of residual environmental effects is based on several criteria. These criteria consider a project’s magnitude, geographic extent, duration, frequency of occurrence, and permanence. Table 4.2 summarizes the rating system used to determine the significance of residual environmental effects following the application of mitigation measures.

Table 4.2: Rating System used to Determine Significance of Residual Environmental Effects Following the Application of Mitigation Measures

Criterion	Criteria Ratings		
	Low (L)	Moderate (M)	High (H)
Magnitude	Effect is evident only at or nominally above baseline conditions	Effect is likely to be measurable over baseline conditions, however, is less than regulatory criteria, a published guideline value, or a level that might measurably affect the quality, quantity, value or use of a VEC	Effect may exceed a regulatory criteria, a published guideline value, or a level that might measurably affect the quality, quantity, value or use of a VEC
Geographic Extent	Effect is most likely to be limited to the project site/footprint	Effect is likely to extend into areas adjacent to the project site/footprint boundary	Effect is likely to extend into areas beyond those adjacent to the project site/footprint boundary
Duration	Effect is most likely to be evident only during one of the following phases of the project: site preparation, construction or decommissioning	Effect is likely to be evident during construction, decommissioning and/or operations phase of the project	Effect is likely to be evident beyond the life of the project
Frequency	Conditions or	Conditions or phenomena	Conditions or phenomena

Criterion	Criteria Ratings		
	Low (L)	Moderate (M)	High (H)
	phenomena causing the effect occur only once	causing the effect may occur more than once, but infrequently	causing the effect are likely to occur at regular or frequent intervals
Permanence	Effect is likely to be reversible over a short period of time (e.g., within several days or months) after the completion of the activity causing the effect	Effect is likely to be reversible over an extended period of time (e.g., a growing season, following a freshet)	Effect is likely to be permanent

After the application of these definitions, an environmental effect is assessed to be either a negligible effect, a minor adverse effect or a significant adverse effect, according to the following definitions:

a) Negligible Effect (NEG) (Not Significant) are those environmental effects which, after taking into consideration applicable mitigation measures, have been assessed to have a “low” rating for the majority (i.e., at least 3 out of 5) of the criteria described above and the effect cannot have been assessed to be “moderate” or “high” for either the “magnitude” or “permanence” criteria. Overall, these effects are not likely to be measurable or noticeable beyond the project site / footprint boundary, are only evident during the site preparation, construction or decommissioning phases of the project or occur only once. These effects are generally completely reversible, within a short period of time.

b) Minor Adverse / Mitigable Effects (MIN) (Not Significant) are those environmental effects which, after taking into consideration mitigation measures, have been assessed to have a “low” or “moderate” rating for the majority of the criteria described above. Any effect that has been assessed as “moderate” or “high” for either the “magnitude” or “permanence” criteria (but not both) is considered to be a minor adverse effect (not significant).

c) Significant Adverse Effects (SIG) are those environmental effects which, after taking into consideration mitigation measures, have a magnitude that is approaching a legal regulatory limit (i.e., moderate) or exceeds a legal limit (i.e., high) and exhibit any or all of the following:

- effect extends into areas beyond those adjacent to the project site/footprint boundary;
- effect is evident beyond the life of the project;
- conditions or phenomena causing the effect occur at regular or frequent intervals; and
- effect is permanent.

The significance rating established represents the residual significance of each environmental effect, including accidents and malfunctions, following the application of mitigation measures. Table 4.3 identifies applicable VECs, associated environmental effects, necessary mitigation measures, and the predicted significance of residual adverse environmental effects, for projects covered by this RCSR.

Table 4.3: Potential Environmental Effects for Construction and Decommissioning of Water Wells

The proponent is responsible for observing and abiding by all applicable municipal, provincial/territorial and federal legislation relating to public health and safety, protection of the environment, wildlife habitat, labour codes, land use and zoning regulations, along with acquiring forthwith and prior to commencement of any work, all necessary rights, licenses, approvals and authorizations. This will help mitigate environmental effects associated with any environmental component affected by these projects.

Environmental Component	Description of Effect	Mitigation	Magnitude	Extent	Duration	Frequency	Permanence	Significance of Adverse Effect
<i>Soils</i>	➤ Reduced soil productivity through compaction and topsoil and subsoil mixing	➤ Avoid work during excessively wet site conditions.	L	L	L	L	L	NEG
	➤ Increased soil exposure resulting in erosion or slope instability	<ul style="list-style-type: none"> ➤ Keep site clearing to a minimum to maintain vegetative cover and wind breaks. ➤ Phase work to minimize duration of exposure of disturbed areas at risk. ➤ Install sediment and erosion controls prior to work and maintain until the site has been stabilized. ➤ Where feasible, direct runoff and overland flows away from working areas and areas of exposed or susceptible soils. ➤ Ensure that any discharged fluid is directed to an appropriately sized energy dissipating outlet device to prevent erosion at the point of discharge. 	L	L	L	L	L	NEG
<i>Surface Water Quality</i>	➤ Reduced water quality due to increased sediment loads	<ul style="list-style-type: none"> ➤ Avoid work during excessively wet site conditions. ➤ Restore or re-vegetate work site to pre-construction conditions, to extent possible. ➤ Where feasible, direct runoff and overland flows away from working areas and areas of exposed or susceptible soils. ➤ Ensure drilling/discharge fluid does not enter water bodies. 	L	L	L	L	L	NEG
	➤ Reduced water quality due to introduction of contaminants	<ul style="list-style-type: none"> ➤ Ensure drilling/discharge fluid does not enter water bodies. ➤ Maintain construction equipment in good working order to prevent leaks and spills of fuels, lubricants, hydraulic fluids, or coolants. ➤ Store, handle and dispose of fuel, wastes and hazardous waste materials in accordance with all relevant municipal, provincial, and federal legislation. ➤ Fuel and/or service mobile construction equipment and store hazardous materials at construction sites at a distance greater than 100m from a water body. ➤ Fuelling and/or servicing of immobile construction equipment within 100m of a water body is to be undertaken in a manner such that any spillage will not enter the water body . ➤ Capture, contain and clean up spills and leaks immediately. ➤ Contractor will maintain spill clean up materials on site (e.g. 25 kg of suitable commercial absorbent, 30 m² of 6 mil polyethylene, a shovel and an empty fuel barrel for spill collection and disposal (CPWCC, 1999)). ➤ Notify appropriate Provincial authorities in the event of any reportable spills of petroleum products or hazardous materials. Ensure emergency contact numbers are available on site 	L	L	L	L	L	NEG

Replacement Class Screening Report for Water Well Construction and Decommissioning Projects

Environmental Component	Description of Effect	Mitigation	Magnitude	Extent	Duration	Frequency	Permanence	Significance of Adverse Effect
<i>Groundwater Quantity</i>	➤ Changes in groundwater flow patterns, groundwater levels in aquifers, yields of wells due to interception of aquifers, and increased withdrawal rates and aquifer depletion,	➤ Ensure that pumping rate does not exceed sustainable yields or yields specified in provincial/territorial permits.	L	L	L	L	L	NEG
<i>Groundwater Quality</i>	➤ Reduced groundwater quality due to introduction of contaminants	<ul style="list-style-type: none"> ➤ Ensure refuelling and construction staging areas where contaminants are handled are located off-site where possible, or well away from a water body and from critical wildlife habitat. ➤ Ensure all equipment which comes in contact with water is free of contaminants. ➤ In areas of high concentration of known resources such as oil, gases and salt water aquifers, special permits and consultations may be required to avoid the risk of intersecting such resources. ➤ Ensure that proper drilling depths are targeted and not over drilled. ➤ Municipal and Provincial regulations will be adhered to for the site selection, drilling, testing, design, construction and operation of the well. ➤ Avoid multi aquifer completion. ➤ Mound soil around well head to divert flows away from the well site. 	L	L	L	L	L	NEG
<i>Terrestrial Habitat and Species</i>	➤ Disturbance or destruction of vegetation and habitat	<ul style="list-style-type: none"> ➤ Keep site clearing to a minimum to maintain vegetative cover and wind breaks. ➤ Use existing roads and trails for site access. ➤ Salvage and replace the topsoil stripped and disturbed during the project as quickly as possible to allow quick re-vegetation. ➤ Re-vegetate disturbed areas and exposed soils with species that existed prior to construction or suitable native species. ➤ Avoid vegetation clearing during the sensitive breeding and nesting periods until fledglings have left parental territories, to minimize impacts on migratory birds and in compliance with the Migratory Birds Convention Act. ➤ Dispose of cleared vegetation in such a way as to avoid adverse effects upon surface water or fish habitat. 	L	L	L	L	L	NEG
	➤ Introduction of non-native species, including opportunistic species	<ul style="list-style-type: none"> ➤ Clean all machinery and equipment prior to transport to new construction areas. ➤ Re-vegetate with species that existed prior to construction or suitable natural species. 	L	L	L	L	L	NEG
	➤ Disruption to wildlife nesting and rearing	<ul style="list-style-type: none"> ➤ Survey the area for nests or dens prior to clearing, and avoid disturbing any active nests or dens. ➤ If migratory birds or wildlife are found in the project area, avoid construction activities during sensitive nesting/rearing periods. 	L	L	L	L	L	NEG
<i>Cultural and Heritage Resources</i>	➤ Loss or disruption to cultural and heritage resources	➤ In the event that any cultural or heritage resources are discovered, construction and decommissioning activities will cease and the appropriate provincial authority notified immediately; construction or decommissioning activities will occur as directed by appropriate provincial authorities.	L	L	L	L	L	NEG

4.7 Accidents and Malfunctions

The likelihood of accidents and malfunctions during water well construction and decommissioning projects that would cause negative environmental effects is minimal, after implementing mitigation. Table 4.4 identifies the potential accidents and malfunctions of each phase of the project.

Table 4.4: Potential Accidents and Malfunctions

Project Phase	Physical Works and Project Activities	Accidents and Malfunctions ²				
		Spills and Accidental Releases	Formation Fractures	Vehicle Collisions	Equipment misuse or malfunction	Fires
Construction	Site planning and Selection					
	Site Access	•		•	•	•
	Vegetation Clearing and Grubbing	•			•	•
	Operation of Hand Machinery/Tools	•			•	•
	Operation of Heavy Equipment, Vehicles	•		•	•	•
	Construction of Well Components	•	•	•	•	•
	Disinfection	•			•	
	Earthworks	•		•	•	•
	Seeding/Planting	•			•	
Operation and Maintenance	Operation of Hand Machinery/Tools	•			•	•
	Operation of Heavy Equipment, Vehicles	•		•	•	•
	Operation and Maintenance of Well Components	•		•	•	
	Disinfection	•			•	
Decommissioning	Operation of Heavy Equipment, Vehicles	•		•	•	•
	Closure of Well Components	•		•	•	•
	Disinfection	•			•	
	Earthworks	•		•	•	•
	Seeding/Planting	•			•	

² A – Applies to Sub-class A (Large Diameter Wells), B – Applies to Sub-class B (Small Diameter Wells), • – Applies to all classes

4.8 Cumulative Effects

Cumulative effects may result when VECs are affected by interactions between or among multiple projects. It is necessary to consider past, present, and future projects to determine the full extent of potential environmental effects associated with each project activity.

The desire for this RCSR was heightened after the announcement and implementation of the Federal Government Agricultural Policy Framework (APF). The National Water Supply Expansion Program is one component of the APF that is a Federal-provincial-industry partnership providing technical and financial assistance to individuals and groups to ensure safe and sustainable rural water supplies. AAFC national programs currently support initiatives pertaining to ground water planning and strategic studies to better understand the nature of the resource and to ensure it's sustainability. Through such work, provincial regulating agencies will be better able to fulfill their responsibilities related to the sustainable allocation of ground water resources.

The water well construction and decommissioning projects described under the RCSR are undertakings that encourage environmentally sustainable farming practices.

Consideration of the cumulative effects associated with projects covered in this RCSR includes all project activities associated with the farm operations. Potential interactions between other projects and activities outside the farm site are also assessed for their potential to result in cumulative effects. Based on knowledge of potential environmental effects and past experience with water well construction and decommissioning projects, it is possible to predict potential cumulative effects resulting from the combination of projects known at the time of declaration of this replacement class screening report.

Water well construction and decommissioning projects have the potential to interact with: 1) other well construction or decommissioning projects; 2) farm operational activities and; 3) projects/activities occurring outside the site boundaries.

Interactions between water well construction and decommissioning projects

Water well construction or decommissioning projects within this RCSR are unlikely to interact with each other. The proper development of water well projects limits the number of wells located in a certain area. Proper planning and siting of water well projects takes into account the location of surrounding wells and the cumulative demand they would place on the associated aquifer. In addition, the environmental effects associated with water well construction and decommissioning projects, as defined by this RCSR, have been found to be negligible, insignificant and limited to the immediate area of the project. Considering these factors, individual water well construction and decommissioning projects are not likely to interact with each other and contribute to significant adverse cumulative effects.

Interactions between water well construction or decommissioning projects, and farm operational activities

Interactions between water well construction or decommissioning projects, and farm operation activities must be factored into the consideration of cumulative effects.

Generally, farm operational activities within the project area have been taking place for extended periods of time, and the immediate environment has been routinely exposed to these activities prior to any water well construction or decommissioning projects. In the case of water wells, farm operational activities are routinely located near the project site, however, direct

contact between the well site and routine farm operational activities is limited. Since the water drawn from wells is used in an off site location, there is little need for farm activities to be located directly near a water well site. Other farm activities are often located outside the project area and direct interaction is not likely to occur.

Water well construction and decommissioning projects, within this RCSR are seen to be benign and generally a benefit to the surrounding area by improving environmental quality, by properly constructing or decommissioning a water well to prevent aquifer contamination. Considering the limited interaction of water well construction and decommissioning projects with other farm operational activities, it can be determined that significant adverse cumulative effects are not likely to occur.

Interactions between water well construction and decommissioning projects, and projects/activities outside site boundaries

The interactions between water well construction and decommissioning projects, and projects/activities outside the site boundaries must also be considered during cumulative effects assessment.

Water well construction and decommissioning projects are located in farm yards, farm sites or associated lands and therefore are only exposed to typical farm operations and not likely to interact directly with farming activities. Effects such as aquifer draw down interference, depletion and changes in ground water flow patterns that may affect others outside the project and farming areas are not considered a significant adverse environmental effect after implementation of mitigation measures.

Water well construction and decommissioning projects, within this RCSR are seen to be benign and generally a benefit to the surrounding area by improving environmental quality, by properly constructing or decommissioning a water well to prevent aquifer contamination, aquifer draw down, aquifer depletion, and changes in ground water flow patterns. Considering the limited interaction of water well construction and decommissioning projects with activities outside the project boundaries, it is unlikely that significant adverse cumulative environmental effects will occur.

5.0 ROLES AND RESPONSIBILITIES

The following section discusses, in general terms, the federal, provincial and territorial regulatory requirements and coordination mechanisms for water well construction and decommissioning projects.

5.1 *Responsible Authorities*

AAFC is the only RA involved in the environmental assessment process of water well construction and decommissioning projects covered by this RCSR. No federal authorizations, permits, or approvals are required for these projects; no other federal departments are expected to be involved in the environmental assessment process. There is potential for other RAs to become involved in the project (e.g. funding); if any other RAs are involved, then the RCSR would not apply.

5.2 *Federal Authorities*

No other FAs have been identified which are likely to require an environmental assessment of the project under Section 5 of the Act or to possess specialist or expert information or knowledge that is necessary to conduct the environmental assessment of the water well construction and decommissioning projects covered by this RCSR. No other federal departments are expected to be involved in the environmental assessment process. Any projects which require an environmental assessment by any other RA will not be covered by this RCSR.

5.3 *Provincial/Territorial Coordination*

The Act allows the Minister of the Environment to enter into agreements with provincial and territorial governments relating to the environmental assessment of projects where both governments have an interest. These bilateral agreements provide guidelines for the roles and responsibilities of each government in the EA of such projects. Several bilateral agreements have been signed and others are currently under negotiation. FAs and provincial agencies must adhere to the bilateral agreements where they are in place.

In some provinces certain water well construction and decommissioning projects will trigger the provincial environmental assessment legislation but only projects not requiring a provincial/territorial environmental assessment will be covered by this RCSR.

Provincial/territorial regulatory requirements for water well construction and decommissioning projects vary by province and territory. Standard practices or guidelines relating to project siting, construction, operation, and/or decommissioning may exist in conjunction with, or independently of, provincial/territorial regulations. Some projects may require an authorization, permit, approval, or licence from a provincial/territorial government agency or authority. Generally, water well construction and decommissioning projects may require provincial/territorial approval to conduct exploratory drilling, develop new or maintain existing wells, withdraw groundwater, or confirm decommissioning.

Projects involving work in provincially designated sites of special concern (e.g., Areas of Natural and Scientific Interest, Environmentally Significant Areas, etc.), potentially affecting provincial

species at risk or of special concern, or providing water for communities or groups will warrant consultation with the provincial authorities responsible for natural resource management (e.g., Provincial Ministries of Environment, Provincial Ministries of Natural Resources, Conservation Authorities) and will not be covered by this RCSR.

5.4 The Proponent

Project proponents are responsible for providing project specific information to AAFC and for ensuring that mitigation measures described in the RCSR are implemented. Proponents are also responsible for ensuring that the project is conducted in accordance with accepted industry practices, obtaining all relevant licenses, permits, and authorizations and ensuring that the project meets all federal, provincial/territorial, and municipal legislative requirements. All relevant licenses, permits, approvals, or authorizations must be made available to AAFC upon request.

6.0 Procedures for Amending the Replacement Class Screening Report

The purpose of an amending procedure is to allow the modification of the RCSR after experience has been gained with its operation and effectiveness. The reasons for such modification may include:

- clarification of ambiguous areas of document and procedures;
- streamlining or modifying the planning process in areas where problems may have arisen;
- minor modifications and revisions to the scope of assessment to reflect new or changed regulatory requirements, policies or standards; and
- new procedures and environmental mitigation practices that have been developed over time.

The RA will notify the Agency in writing of its interest to amend the RCSR. It will discuss the proposed amendments with the Agency and affected federal government departments and may invite comment from stakeholders and the public on the proposed changes. The RA will then submit the amended RCSR to the Agency, along with a request that the Agency amend the RCSR and a statement providing a rationale for the amendment.

The Agency may amend the RCSR without changing the declaration period if the changes:

- are minor;
- represent editorial changes intended to clarify or improve the screening process;
- do not materially alter either the scope of the projects subject to the RCSR or the scope of the assessment required for these projects; and
- do not reflect new or changed regulatory requirements, policies or standards.

The Agency may initiate a new declaration for the RCSR for the remaining balance of the original declaration period or for a new declaration period if the changes:

- are considered to be substantial; or
- represent modifications to the scope of the projects subject to the class or the scope of the assessment required for these projects.

6.1 *Term of Application*

This RCSR will be in effect for a period of five years, from the date of declaration.

7.0 List of References

AAFC – PFRA. 2004. Water Well Abandonment and Decommissioning. (Online) Available: http://www.agr.gc.ca/pfra/water/wells_e.htm (September 12, 2004)

AAFC – PFRA. 2004. Guide for Sealing Abandoned Water Wells in Manitoba (Online) Available: http://www.agr.gc.ca/pfra/water/abwells_e.htm (September 12, 2004)

Agricultural & Biological Engineering Department, Purdue University. 2001. Water Well Location and Condition on the Farm. (Online) Available: <http://www.epa.gov/seahome/well/src/main.htm> (September 12, 2004)

Alberta Agriculture, Food and Rural Development, Alberta Environmental Protection and Agriculture and Agri-Food Canada, 2001. Water Wells...that last for generations. (Online) Available: [http://www1.agric.gov.ab.ca/\\$department/deptdocs.nsf/all/wwg404?opendocument](http://www1.agric.gov.ab.ca/$department/deptdocs.nsf/all/wwg404?opendocument) (September 12, 2004)

CPWCC (Canadian Pipeline Water Crossing Committee). 1999. Watercourse Crossings - 2nd Edition.

Ministry of Agriculture and Food, Ontario Government. 2004. Water Well Publications. (Online) Available: <http://www.gov.on.ca/OMAFRA/english/environment/water/publications.htm#Important> (September 12, 2004)

Glossary of Technical Terms

Abandonment

The long term or permanent cessation of an operation and the discontinued service of a physical work.

Agricultural Land

Improved and unimproved land which is used primarily in support of the primary production of crops and livestock, such as cultivated land, forages, pasture (native and non-native), orchards, shelterbelts, and other treed areas, farmsteads and building sites and associated access routes.

Aquifer

A porous and permeable geological formation which stores, transmits, and yields significant and usable amounts of water to wells and springs.

Artesian Well

A type of well which normally gives a continuous flow, the water being forced upwards by hydrostatic pressure.

Canadian Environmental Assessment Registry (CEAR)

An electronic internet listing of all environmental assessments conducted by all Responsible Authorities under the CEAA. The listing is called the Canadian Environmental Assessment Registry (CEAR) and is available to the public through the Agency's internet site (http://www.ceaa-acee.gc.ca/050/index_e.cfm).

Cumulative Environmental Effects

The effect on the environment which results from effects of a project when combined with those of other past, existing and imminent projects and activities. These may occur over an extended period of time and distance.

Decommissioning

The sealing, dismantling, and/or removal of a physical work where the operation or use has permanently ceased and service has been discontinued; decommissioning is often regulated or carried out in accordance with standards or pre-defined conditions designed to ensure safety and security and to mitigate potential environmental effects.

Environment

The components of the Earth, including

- a) land, water, air, including all layers of the atmosphere,
- b) all organic and inorganic matter and living organisms, and
- c) the interacting natural systems that include components referred to in (a) and (b).

Environmental Effect

- a) any change that the project may cause in the environment, including any change it may cause to a listed wildlife species, its critical habitat or the residences of individuals of that species, as defined in SARA;
- b) any activity of the project that changes the health and socio-economic conditions, physical and cultural heritage, the current use of lands and resources for traditional purposes by

aboriginal persons or any structure, site or thing that is of historical, archaeological, paleontological or architectural significance, and

b) any change to the project that may be caused by the environment.

Farm

Any operation involved in the primary production of agricultural crops or livestock. For the purposes of applying the Act, greenhouse operations and intensive livestock operations are included in the definition of farm.

Federal Authority

Federal authority is a Minister of the Crown, an agency or body accountable in right of Canada. Federal Authorities may provide expert advice to the Responsible Authorities for environmental assessments.

Fish Habitat

Under the federal *Fisheries Act*, “fish habitat” is defined as: spawning grounds and nursery, rearing, food supply and migration areas on which fish depend directly or indirectly in order to carry out their “life processes” . The *Fisheries Act* also defined “fish” to include all the life stages of “fish, shellfish, crustaceans, marine animals and marine plants”.

Fixed Structure

Means the electrical, heating, fire-prevention, plumbing or security structure of an existing building, but does not include a structure that is intended to produce goods or energy.

Follow-up program

A program for verifying the accuracy of the environmental assessment of a project; and/or determining the effectiveness of any measures implemented to mitigate the potential adverse environmental effects of the project..

Footprint

The area of land occupied by a building or structure at ground level.

Groundwater

Water which is found in the saturated subsurface zone where water completely fills all the soil or rock pores.

Migratory Bird Sanctuary

Federal lands that are protected under the Migratory Bird Sanctuary Regulations.

Mitigation

Mitigation refers to activities that eliminate, reduce or control the adverse environmental effects of the project, and includes restitution for any damage by replacing, restoring or compensating habitat or any other means.

Modification

An alteration to a physical work that introduces a new structure or eliminates an existing structure and does not alter the purpose or function of the work, but does not include an expansion.

Monitoring Well

A well used either to collect water samples for purposes of water quality testing, or to measure groundwater levels and is not normally a producing well.

Physical Work

Human-made structures/equipment/materials set in a fixed location. Physical works do not include constructed items that are portable (e.g. table, tractor).

Piezometer

A solid walled pipe open only at its lower end which measures the head, or water pressure at its lower end and hence the elevation of the water table.

Polluting Substance

A substance that, if added to a water body, is likely to degrade or alter or form part of a process of degradation or alteration of the physical, chemical or biological conditions of the water body to an extent that is detrimental to its use by human beings, animals, fish or plants.

Project

- In relation to a physical work, any proposed construction, operation, modification, decommissioning, abandonment, or other undertaking in relation to that physical work; or
- Any proposed physical activity not relating to a physical work that is prescribed in the *CEAA* regulations.

Residual Environmental Effects

Residual Environmental Effects are found when a project still has adverse effects even after mitigation is applied. Thus, residual effects are the effects remaining after mitigation.

Responsible Authority

A federal authority that is required to ensure that an environmental assessment is conducted for a project which has a *CEAA* trigger.

Right-of-Way

With respect to the Exclusion List Regulations, land that is subject to a right-of-way and that is developed for an electrical transmission line, pipeline, road, or other similar linear feature.

Scope of Project or Assessment

Both the scope of the project and assessment need to be delineated in the environmental assessment. Scoping refers to determining the spatial and temporal boundaries i.e., what area is affected and for how long. Scope of the project refers to what activities or works are triggered by *CEAA*. Scope of the assessment refers to the area and duration of environmental effects considered within the assessment.

Significant Adverse Environmental Effects

For the environmental assessment, adverse effects are judged as to whether they are likely and significant. Adverse effects occur if the project degrades the quality of the environment. Significance is determined by evaluating severity of impacts based on the duration and frequency, and the area affected by the project, including cumulative effects.

Species at Risk

The Committee on the Status of Endangered Wildlife in Canada (COSEWIC) defines Species at Risk as either extinct (a species that no longer exists), extirpated (a species no longer existing in Canada but occurring elsewhere), endangered (species facing imminent extirpation or

extinction), threatened (a species likely to become endangered if limiting factors are not reversed), and special concern (a species is of special concern because of characteristics that make it particularly sensitive to human activities or natural events).

Water Body

For purposes of applying the Exclusion List Regulations, a water body means a water body, including a canal, ocean, and wetland, up to the high-water mark, but does not include a sewage or waste treatment lagoon or a mine tailings pond.

Water Table

The level separating the static surface of groundwater, or the saturated zone, from a zone where water in the pores of soil or rock is held up by capillary tension and the unsaturated soil-water zone above.

Wetland

A swamp, marsh, bog, fen or other land that is covered by water during at least three consecutive months of the year. For more clarity, wetlands can be defined in terms of the presence of wetland vegetation -- i.e., land that has the water table at, near, or above the surface or which is saturated for a long enough period to promote wetland processes that are indicated by the presence of wetland vegetation (e.g., reeds, rushes, cattails, and sedges).

Wildlife Area

An area of public lands, administered by the Minister of the Environment, and described in Schedule I of the Wildlife Area Regulations. Note: these lands are referred to as National Wildlife Areas and involve federal lands.

Valued Ecosystem Component (VEC)

Any part of the environment that is considered important by the proponent, public, scientists and government involved in the assessment process. Importance may be determined on the basis of cultural values or scientific concern.

List of Acronyms

AAFC	Agriculture and Agri-Food Canada
APF	Agricultural Policy Framework
BMP	Beneficial Management Practice
CEAR	Canadian Environmental Assessment Registry
COSEWIC	Committee on the Status of Endangered Wildlife in Canada
EA	Environmental Assessment
EC	Environment Canada
FA	Federal Authority
PFRA	Prairie Farm Rehabilitation Administration
PVC	Polyvinyl Chloride
RA	Responsible Authority
RCSR	Replacement Class Screening Report
SARA	Species at Risk Act
VEC	Valued Ecosystem Component

Appendix 1 Contract Mitigation

1. Proponents are responsible for obtaining and complying with all applicable licenses, permits, approvals, or authorizations and for meeting all legislative requirements.

Part 1- General Mitigation

Equipment and the Introduction of Contaminants

2. Maintain construction equipment properly to prevent leaks and spills of fuels, lubricants, hydraulic fluids, or coolants.
3. Store, handle and dispose of fuel, wastes and hazardous waste materials properly and in accordance with all relevant municipal, provincial, and federal legislation.
4. Avoid fuelling and/or servicing of mobile construction equipment and storing hazardous materials within 100m of a water body. Fuelling and/or servicing of immobile construction equipment within 100m of a water body is to be undertaken in a manner to ensure spillage will not enter the water body.
5. Ensure that the contractor has spill clean up materials on site (e.g. 25 kg of suitable commercial absorbent, 30 m² of 6 mil polyethylene, a shovel and an empty fuel barrel for spill collection and disposal (CPWCC, 1999)). In the event of any reportable petroleum products or hazardous material spills, the spill must be captured, contained and cleaned immediately and appropriate Provincial authorities must be notified. Ensure emergency contact numbers are available on site.
6. Clean all machinery and equipment prior to transport to new construction areas.

Land and Water Protection

7. Use existing roads and trails for site access.
8. Avoid work during excessively wet site conditions.
9. Phase work to minimize duration of exposure of disturbed areas.
10. Keep site clearing to a minimum and maintain vegetative cover and wind breaks.
11. Conserve topsoil by removing, salvaging and stockpiling prior to construction. Topsoil should also be replaced as quickly as possible, to help conserve and allow natural re-vegetation.
12. Install effective short and long-term erosion and sediment controls prior to work and maintain until the site has been stabilized.
13. Divert runoff and overland flow away from working areas and areas of exposed or susceptible soils, where feasible.
14. Restore or re-vegetate all disturbed areas, including riparian areas, to pre-construction conditions, as soon as possible and to the extent possible. All re-vegetation should be done with species that existed prior to construction or suitable native species.

Other

15. Minimize disturbance to fish and wildlife by avoiding sensitive periods (eg. spawning, nesting) and areas (i.e. residences, spawning beds).

16. Cease construction and notify the appropriate provincial authority immediately if any cultural or heritage resources are discovered. If this occurs, construction will occur as directed by the appropriate Provincial authority.

Part 2- Additional Mitigation for Water Well Construction and Decommissioning

17. Ensure that any discharged fluid is directed to an appropriately sized energy dissipating outlet device to prevent erosion at the point of discharge
18. Ensure drilling/discharge fluid does not enter water bodies
19. Ensure that pumping rate does not exceed sustainable yields or yields specified in provincial/territorial permits
20. Ensure refuelling and construction staging areas where contaminants are handled are located off-site where possible, or well away from a water body and from critical wildlife habitat.
21. Ensure all equipment which comes in contact with water is free of contaminants
22. Obtain special permits and carry out consultation, as appropriate in areas of high concentration of known resources such as oil, gases and salt water aquifers, to avoid the risk of intersecting such resources
23. Ensure that proper drilling depths are targeted and not over drilled
24. Adhere to Municipal and Provincial regulations for the site selection, drilling, testing, design, construction, and operation of the well.
25. Avoid multi-aquifer completion.
26. Mound soil around the well site to ensure that flows are diverted away from the well head.